



40) INSTALL 1Ø GROUND SLEEVE AND #2 AL TO POINT 50.

50) INSTALL 1Ø GROUND SLEEVE AND #2 AL TO POINT 60.

60) INSTALL 1Ø GROUND SLEEVE AND #2 AL TO POINT 70.

80) INSTALL XFMR AND #2 AL TO POINT 90.

70) INSTALL 1Ø GROUND SLEEVE AND #2AL TO POINT 80.



A MID-AMERICAN ENERGY HOLDINGS COMPANY  
 7 OF 7  
 Scale 1"=400'  
 Print Date 11/03/11  
 EST ID# 97742

Job Start Date	Post Jobs <input type="checkbox"/>
Job Comp Date	RQII <input type="checkbox"/>
Circuit LVA11	Posted <input type="checkbox"/>

Foreman	Emp #	Job Start Date
CC# 11506	WO# / REG# 005536779	Job Comp Date
CUSTOMER : SCOTT CAMPBELL ADDRESS : LAVA RANCH LAVA HOT SPRINGS, IDAHO	Map String 03410038.0	